- When laundrying, non-clothing cling to the protective net or in the body. Non-baking bulky clothing, laundry guarded to avoid danger.
- The appliance shall not be used as a stool.

- May cause a fire because the heater is winged cap or incorrectly placed, it should not be used with a program that can automatically power on, timer, or other device to the heater.
- This product is forbidden to use in inflammable and explosive materials , and the use of ambient temperature should not exceed 30℃. leave combustible material at least 50 cm, to prevent fires.
- Must ensure that the appliance is disconnected from the power when power outage or moving this appliance.

- Heater surface dirt, use a soft cloth moistened with soap to wipe. Do not use organic solvents such as gasoline, alcohol, prohibited the liquid from entering the inside of the product. Not use in hot, humid, dusty or volatile acid-base oil place.

- Before use , please check the power cord and plug is damaged or not, the power cord do not bend, pull, in order to avoid poor contact。unable to be tilted more than 10 degree or down to the ground to use. Should be placed on a flat plane.

- Never touch the burning window so as not to burn. to avoid overheating, Do not cover the heater.

- Leave or when unused for long periods of time, be sure to cut off the power, unplug the power cord.
- The heater fire protective net is used to prevent direct contact with the heating element when the heater is used, the fire protective net must be installed in place. Fire protective net not provide comprehensive protection of children and the disabled.
- Turn off the power, not the cord, befor you pull the power plug, otherwise it will cause a short circuit, fire, electric shock.
- Do not pull the power plug with wet hands. in the risk of electric shock.
- May not be used in surrounding of the tub, sprinklers , shower, bath or swimming pool.
- Not the heater be placed directly below the power outlet.

- When heating, the absolute prohibition of the hands or foreign objects into the body, can cause injury or damage. Pay special attention to children .

- Children should be supervised to ensure that they will not be playing with the appliance.
- This appliance is not intended to be physical, sensory or mental defects, or lack of experience and common sense people (including children), unless there is a safeguard and responsible supervision



Never use in curtains where easily sucked into place. should be avoided around obstacles material and instability spaces.

MAINTENANCE AND STORAGE:

Shut off power before maintenance and storage

1. If body with oil dirt, must be cleaned to avoid discoloration, damage.
2. After maintenance and cleaning, the original packaging to the order of the various components into the box, placed in the dry place for safekeeping.
3. The appliance just to do general external cleaning and maintenance.
4. Use neutral detergent, and then a clean, soft cloth to wipe.
5. Avoid direct wash water.
6. Don't use thinner, toluene, acid lotion, oil to wipe, to avoid discoloration or deterioration.

TROUBLESHOOTING

FAULT	CAUSE	SOLUTION
NOT TURN ON	•The power cord is not plugged or bad •Do not press on / off key •Body has been damaged	•To ensure good contact plug in the power •Press on / off key •Send to a service point for repair
NOT TURN OFF	•Do not press on / off key •Body has been damaged	•Press on / off key •Send to a service point for repair

SPECIAL NOTE:

We will remain the right to refinements and modifications to the product and manuals, product structure is subject to change without notice. Part of the picture in the manual is a schematic diagram, for reference only, if the picture does not match with the physical, to prevail in kind.

USER' S MANUAL



Please read this manual carefully before use

INTRODUCTION

This heater has reasonable design, beautiful shape, safe, reliable, easy to operate, with high thermal efficiency, thermal sensing fast, energy saving and long life and other advantages, we use environmentally friendly materials, suitable for families and similar places.

TECHNICAL SPECIFICATION

MODEL	VOLTAGE	POWER INPUT	CONTROL
LTG-1300M	220V 50Hz	1305W	MECHANICAL CONTROL
LTG-1600M		1600W	MECHANICAL CONTROL
LTG-1800M		1800W	MECHANICAL CONTROL
LTG-2000M		2000W	MECHANICAL CONTROL
LTG-2200M		2200W	MECHANICAL CONTROL

PRODUCT STRUCTURE DIAGRAM

MACHINE



CONTROL COMPONENTS



Ⅰ+ Ⅱ = Ⅲ (2 gear switch together is max. power input)

ELECTRICAL SCHEMATICS



CASTERS ASSEMBLE WAY:

A. Bolts screwed the caster into caster holder, and tighten it. another caster is the same. see Figure 1



FIGURE 1

B. Then the assembled caster snaped as the direction of arrow into left column and right column, the other side of the caster assembly is the same see Figure 2





FIGURE 2

C. After the assembled casters are installed well, put the product upside down, on the ground or other supporting surface can be. see Figure 3



FIGURE 3

INSTRUCTIONS FOR USE:

Before use to check whether the name label voltage and frequency comply with local supply conditions. Boot three minutes or so, there may be a slight odor, noise emitted, this is normal and will not cause harm to human health.

- Plug the power plug into AC220V well grounded and the current capacity of more than 10A power outlet, then power on.
- Adjust gear switch to “Ⅰ” or “Ⅱ” level, or press “Ⅰ”,“Ⅱ” together meantime, adjust the temperature knob according to you.

TIP OVER PROTECTION:

1. Products must be placed to the level for normally running.
2. In order to prevent accidents caused by the dumping machine , we add tip over switch for protection, when product horizontal tilt 60° . it will auto turn off all outputs. you need to put the machine to the level to reboot.

PRECAUTIONS:

- Before first use, Please check your voltage requirements is consistent with the product name label.
- If the power cord is damaged, avoid a hazard, must be replace by the manufacturer, or the maintenance department or similarly qualified persons.